


ASSEMBLY INSTRUCTIONS

ITEM NO: UL-TR002-1


PARTS LIST:

A  10 pcs	B pcs	C pcs
D pcs	E pcs	F pcs
G pcs	H pcs	I pcs
J pcs	K pcs	O pcs


RESOLVE VIEW



①: Ax4



②: Ax6




ASSEMBLY INSTRUCTIONS

ITEM NO: HX-MB002


PARTS LIST:

A  24 pcs	B  1 pcs	C  10 pcs
D pcs	E pcs	F pcs
G pcs	H pcs	I pcs
J pcs	K pcs	O pcs

RESOLVE VIEW



①:



②:

